NEXSAN




Nexsan


VEEAM HARDENED REPOSITORY SETUP AND INTEGRATION

©Nexsan. All Rights Reserved.

Follow the Instructions on the Main Screen once the server is booted up

1. Default User Account: vhradmin
2. Default Password: vhradmin
3. Current Live Password: Tuna#9BigFrogJet$





©Nexsan. All Rights Reserved.


NEXSAN

Setting Up the Veeam Hardened Repository as a Veeam Backup Repository

1.Start the SSH service on the hardened repository server.
Note: If the password is not clearly visible, stop and restart the SSH service to generate a new, readable one.

2.Make note of the username and password displayed — these credentials will be used for the initial repository setup in Veeam (single-use only).






©Nexsan. All Rights Reserved.

NEXSAN


If Veeam Backup & Replication Is Not Installed

1. Download the latest version of Veeam Backup & Replication from the official Veeam website.
2. Run the installer and follow the setup wizard.
    1. Accept all default settings, unless specific customization is required for your environment.
3. Once installation is complete, launch the Veeam Backup & Replication Console.
4. Navigate to Backup Infrastructure > Add Repository to begin adding your storage target.



©Nexsan. All Rights Reserved.


Select -



©Nexsan. All Rights Reserved.

NEXSAN

Select – Linux “Hardened Repository”



©Nexsan. All Rights Reserved.


NEXSAN

Provide a username and password

from VHR SSH



Select Next to confirm SSH key




©Nexsan. All Rights Reserved.

NEXSAN

Select “Apply”


following account verification



©Nexsan. All Rights Reserved.

NEXSAN


Select “Next” on completion



©Nexsan. All Rights Reserved.

NEXSAN

Select “Finish” at summary screen



©Nexsan. All Rights Reserved.

NEXSAN


Select “Next” to select repository,

Followed by “Browse”

Select “/mnt/veeam-repository01”

Change any retention settings are required

Select “Next”




©Nexsan. All Rights Reserved.


NEXSAN

Confirm Settings for write cache “SSD/NVMe”

if available



Select “Apply” and “Next”




©Nexsan. All Rights Reserved.

NEXSAN

Complete the VHR Integration

Click **Finish** to complete the Veeam Hardened Repository (VHR) integration.




©Nexsan. All Rights Reserved.

NEXSAN

Final Step: Disable SSH Access on the Nexsan VHR






©Nexsan. All Rights Reserved.

NEXSAN

Setup and Integration Completed



©Nexsan. All Rights Reserved.

NEXSAN

Setup and Integration Completed

